



**INTERCONNECTIONS KIT, P/N 400985,
INCLUDES**

QTY	PART NO	DESCRIPTION
2	100319	Adaptor, 1/8 in. Tube x 1/8 in. NPTM
1	100327	Tee, 2T
1	101563	Filter, 2T
1	101980	Union, 2P
1	101982	Reducer, 4P x 2P
2	101988-Z	Tubing, SS, .125 OD x 100 cm LG
1	102115	Quick Connect, AN4M
1	102116	Quick Connect, 1/8 in. NPTF
1	401459	Quick Connect and Stand Assembly

**PARTS ON TEST PORT OR IN
ACCESSORIES OF PG7000**

1	101200	Collar
1	100272	Gland
1	400518	1/8 in. Tube x DH 200 M Adaptor

**TO PNEUMATICALLY CONNECT THE
PG7000 OR RPM TO THE PPC OR MPC**



If you are using an RPM (not a PG7000) go directly to Step 2b.

- Remove gland, collar and plastic plug from the PG7000 TEST port.

- Install gland and collar onto 1/8" tube x DH200 male adaptor supplied in PG7000 accessories.



The collar threads left-handed. Ensure it is securely attached. The plastic plug is not used.

- PG7000 - Screw the adaptor (as assembled) into the PG7000 test port. Torque to 15 Nm (Newton meter).
 - RPM3 - Screw 1/8 in. tube x 1/8 in. NPT male adaptor into the RPM3 test port using teflon tape as seal.
- Connect tee and filter assembly to quick connect stand assembly.
- Screw 1/8 in. tube x 1/8 in. NPT male adaptor into PPC test port using Teflon tape as a seal.
- Mount quick connect stand on bench (mounting holes provided).
- To connect PG7000 or RPM3 test port to the quick connect stand cut 1/8" SS tubing to desired length and Swage nut together.
- To connect PPC to the quick connect stand cut 1/8 in. SS tubing to desired length and Swage nut together.



1/8 in. SS tubing can be bent by hand to desired shape but use caution not to kink the tube.

PG7000, RPM, PPC and MPC are trademarks, registered and otherwise, of DH Instruments, Inc.