

---

## **PARTS INCLUDED IN molbox1/MPC1 RACK MOUNT KIT**

1 ea.	122336	molbox1/MPC1 Front Panel	4 ea.	100972-Z	M4 Hex Nut
2 ea.	122337	molbox1 Rack Mount Bracket	8 ea.	100989-Z	M4 X 12 PHP Screw
12 ea.	100971-Z	M4 Lock Washer	1 ea.	560008	molbox1/MPC1 Rack Mount Kit Instruction Sheet

The brackets are attached to the side panels of molbox1/MPC1 using eight (8) lock washers and eight (8) M4 X 12 PHP screws. The front panel is then attached to the brackets using four (4) lock washers and four (4) nuts.

The rack mount panel can be oriented so that the opening is on the left or right side.

- 
- *Depending on the mounting position of the system, it may be necessary to remove the stationary feet on molbox1 or MPC1. The bottom panel will need to be removed to get access to the screws securing the feet. This can be accomplished by removing the four (4) screws that secure the panel. The screws that secure the bottom are located under the adjustable feet. These flaps need to be pried up to get access to the screws. The screws attaching the feet can now be removed.*

**DH Instruments, Inc.**  
4765 East Beautiful Lane  
Phoenix AZ 85044-5318  
USA

molbox1 and MPC1 are trademarks  
of **DH Instruments, Inc.**

Tel 602.431.9100  
Fax 602.431.9559  
dhi@dhinstruments.com  
www.dhinstruments.com