

**NOTE FOR USERS OF NEW
molbox1™
WITH EXISTING molblocs™**

If you are going to be using this new molbox1 with previously delivered molblocs, there is the possibility that the molbloc temperature measuring circuit is not compatible with the new molbox1.

To check compatibility, turn on the molbox1 with the molbloc connected. If the molbox1 autotests and goes to the main run screen normally, the molbloc is compatible with the molbox1. If you encounter the message "PRT ERROR", the molbloc is not compatible with the molbox1. If used, it may give out of tolerance flow indications.

If you observe a "PRT ERROR" message when initializing a molbloc, contact **DHI** Technical Service for information on upgrading the molbloc for compatibility.

molbox1 and molbloc are trademarks of **DH Instruments, Inc.**