

DESCRIPTION

This kit includes the mating connector for the PPC2+ Drivers Port. It also includes a ferrite sleeve which does not affect the performance of the PPC2+, but is required to meet the CE emissions requirements in Europe.

GENERAL INSTALLATION

Refer to Section 7-1 **DRIVERS** of your PPC2+ Operation and Maintenance Manual for drivers wiring instructions.

To install the ferrite:

- ❶ Slide the ferrite and heat shrink tubing onto the cable before attaching to the wires to the enclosed connector.
- ❷ After connecting the wires, as required for your application, slide the ferrite as close as possible to the PPC2+ connector.
- ❸ Shrink the heat shrink over the ferrite to hold it in place.p2

PPC2 and PPC2+ are trademarks, registered and otherwise, of **DH Instruments, Inc.**