

Instruction Sheet

The following parts are included in the RPM Rack Mount Kit, P/N 400129:

Qty	Part No.	Description
• (1) ea	100934	Front Panel
• (2) ea	100883	Mounting Shelves
• (1) ea	100935	Cover Panel
• (8) ea	100984-Z	m3 x 6 Flat Head Screws
• (4) ea	101000-Z	m3 x 6 Pan Head Screws
• (4) ea	100997-Z	m3 x 10 Flat Head Screws
• (4) ea	100969-Z	m3 Lock Washer
• (4) ea	100970-Z	m3 Hex Nut

The RPM1 rack mount kit can hold one or two units. The RPM should first be secured to the mounting shelf using (2) m3 x 6 pan head screws. The shelf assembly can then be attached to the front panel using (4) m3 x 6 flat head screws.

If two RPMs are being installed: Repeat the above procedure for the other unit.

If only one unit is being installed: The cover plate can be placed over the opening and secured to the unused mounting shelf using (4) m3 x 10 flat head screws, (4) m3 lock washers, and (4) m3 hex nuts.

RPM1 is a trademark, registered and otherwise, of DH Instruments, Inc.